DENON

STEREO CASSETTE TAPE DECK

DN-770R

OPERATING INSTRUCTIONS

IMPORTANT TO SAFETY

WARNING:

TO PREVENT FIRE OR SHOCK HAZARD, DO NOT EXPOSE THIS APPLIANCE TO RAIN OR MOISTURE.

CAUTION:

1. **Handle the power supply cord carefully**
   Do not damage or deform the power supply cord. If it is damaged or deformed, it may cause electric shock or malfunction when used. When removing it from wall outlet, be sure to remove by holding the plug attachment and not by pulling the cord.
2. **Do not open the top cover**
   In order to prevent electric shock, do not open the top cover. If problems occur, contact your DENON DEALER.
3. **Do not place anything inside**
   Do not place metal objects or spill liquid inside the cassette tape deck. Electric shock or malfunction may result.

Please, record and retain the Model name and serial number of your set shown on the rating label.
Model No. DN-770R Serial No.

CAUTION: TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE COVER (OR BACK). NO USER SERVICEABLE PARTS INSIDE. REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.

The lightning flash with arrowhead symbol within an equilateral triangle is intended to alert the user of the presence of uninsulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.

The exclamation point within an equilateral triangle is intended to alert the user of the presence of important operating and maintenance (servicing) instruction in the literature accompanying the appliance.

FOR U.S.A. & CANADA MODEL ONLY

CAUTION

TO PREVENT ELECTRIC SHOCK DO NOT USE THIS (POLARIZED) PLUG WITH AN EXTENSION CORD, RECEPTACLE OR OTHER OUTLET UNLESS THE BLADES CAN BE FULLY INSERTED TO PREVENT BLADE EXPOSURE.

SAFETY INSTRUCTIONS

1. Read Instructions – All the safety and operating instructions should be read before the applicance is operated.
2. Retain Instructions – The safety and operating instructions should be retained for future reference.
3. Heed Warning – All warnings on the applicance and in the operating instructions should be adhered to.
4. Following Instructions – All opeerating and use instructions should be followed.
5. Water and Moisture – The appliance should not be used near water – for example, near a bathtub, washbbowl, kitchen sink, laundry tub, in a wet basement, or near a swimming pool, and the like.
6. Carts and Stands – The appliance should be used only with a cart or stand that is recommended by the manufacturer.

6A. An appliance and cart combination should be moved with care. Quick stops, excessive force, and uneven surfaces may cause the applicance and cart combination to overturn.

7. Wall or Ceiling Mounting – The appliance should be mounted to a wall or ceiling only as recommended by the manufacturer.
8. Ventilation – The appliance should be situated so that its location or position does not interfere with its proper ventilation. For example, the appliance should not be situated on a bed, sofa, rug, or similar surface that may block the ventilation openings; or, placed in a built-in installation, such as a bookcase or cabinet that may impede the flow of air through the ventilation openings.
9. Heat – The appliance should be situated away from heat sources such as radiators, heat registers, stoves, or other appliances (including amplifiers) that produce heat.
10. Power Sources – The appliance should be connected to a power supply only of the type described in the operating instructions or as marked on the appliance.
11. Grounding or Polarization – Precautions should be taken so that the grounding or polarization means of an appliance is not defeated.
12. Power-Cord Protection – Power-supply cords should be routed so that they are not likely to be walked on or pinched by items placed upon or against them, paying particular attention to cords at plugs, convenience receptacles, and the point where they exit from the appliance.
14. Cleaning – The appliance should be cleaned only as recommended by the manufacturer.
15. Power Lines – An outdoor antenna should be located away from power lines.
16. Outdoor Antenna Grounding – If an outside antenna is connected to the receiver, be sure the antenna system is grounded so as to provide some protection against voltage surges and built-up static charges. Article 810 of the National Electrical Code, ANSI/NFPA 70, provides information with regard to proper grounding of the mast and supporting structure, grounding of the lead-in wire to an antenna-discharge unit, size of grounding conductors, location of antenna-discharge unit, connection to grounding electrodes, and requirements for the grounding electrode. See Figure A.
17. Nonuse Periods – The power cord of the appliance should be unplugged from the outlet when left unused for a long period of time.
18. Object and Liquid Entry – Care should be taken so that objects do not fall and liquids are not spilled into the enclosure through openings.
19. Damage Requiring Service – The appliance should be serviced by qualified service personnel when:
    A. The power-supply cord or the plug has been damaged; or
    B. Objects have fallen, or liquid has been spilled into the appliance; or
    C. The appliance has been exposed to rain; or
    D. The appliance does not appear to operate normally or exhibits a marked change in performance; or
    E. The appliance has been dropped, or the enclosure damaged.
20. Servicing – The user should not attempt to service the appliance beyond that described in the operating instructions. All other servicing should be referred to qualified service personnel.

FIGURE A
EXAMPLE OF ANTENNA GROUNDING AS PER NATIONAL ELECTRICAL CODE


ANTENNA LEAD IN WIRE
GROUND CLAMP
ANTENNA DISCHARGE UNIT (NEC SECTION 810-20)
ELECTRIC SERVICE EQUIPMENT
GROUNDING CONDUCTORS (NEC SECTION 810-21)
GROUND CLAMPS
POWER SERVICE GROUNDING ELECTRODE SYSTEM (NEC ART 250, PART H)
NEC - NATIONAL ELECTRICAL CODE



Avoid high temperatures
Allow for sufficient heat dispersion when installed on a rack.



Handle the power cord carefully. Hold the plug when unplugging the cord.



Keep the set free from moisture, water, and dust.



Unplug the power cord when not using the set for long periods of time.



"(For sets with ventilation holes)
Do not obstruct the ventilation holes.



Do not let foreign objects in the set.



Do not let insecticides, benzene, and thinner come in contact with the set.



Never disassemble or modify the set in any way.

Thank you very much for purchasing the DENON component stereo cassette tape deck.
DENON proudly presents this advanced tape deck to audiophiles and music lovers as a further proof of DENON's non compromising pursuit of the ultimate in sound quality. The high quality performance and easy operation are certain to provide you with many hours of outstanding listening pleasure.

Please check to make sure the following items are included with the main unit in the carton:

(1) Operating Instructions 1
(2) Connection Cords 2
(3) Remote control box connection wire 1
(4) Remote control box schematic diagram 1

- TABLE OF CONTENTS -

FEATURES 5
CONNECTION 5
NAMES AND FUNCTION OF PARTS 6, 7
CASSETTE TAPES 7
AUTOMATIC TAPE SELECTION 8
PLAYBACK 8
RELAY PLAY 9
TWIN OUTPUT 9
MUSIC SEARCH SYSTEM 9
RECORDING 10
PROPER RECORDING LEVEL 10
REC/REC MUTE AND REC PAUSE BUTTON 10
AUTO-STANDBY 11
TWIN RECORDING 11
RELAY RECORDING 11
DUBBING 12
DECK A/B SELECT AND MEMORY STOP 13
DOLBY B AND C NOISE REDUCTION SYSTEM 14
DOLBY HX-PRO HEADROOM EXTENSION SYSTEM 14
MAINTENANCE 14
TROUBLESHOOTING 15
SPECIFICATIONS 15
WIRED REMOTE DIAGRAM 16

FEATURES

- Computer Controlled Mechanism
- Dual Power Supply
- Dolby HX-Pro Headroom Extension System (deck B only)
- Dolby B & C Noise Reduction Systems (A/B Independent)
- Computing Tape Counter with 4-Digit Readout and Memory Stop
- Music Search System
- FL Peak Level Meters
- Auto Tape Selector
- 2-Speed Dubbing
- Relay Playback
- Twin Recording and Relay Recording
- 19-inch Rack Mountable
- Speed Control of Approximately ±12% (A/B Independent)
- Accurate Music Search System
- Display Memory Back-up
- Twin Output
- Auto-standby

CONNECTION

Leave your entire system (including this cassette deck) turned off until all connections between the deck and other components have been completed.



- **Connecting the Deck to an Amplifier (Mixer)**
  Before connecting the deck to your amplifier, please review your amplifier's instruction manual. Use the white plugs for the left channel and red plugs for the right channel.
- **Tape Dubbing**
  Many stereo amplifiers and receivers have tape dubbing circuitry so that tape duplication can be performed between two or more tape decks. Review your amplifier's instruction manual for a full explanation of this mode of operation.
- **Connecting Headphones**
  To listen through headphones, plug your headphones into the PHONES jack.
- **Installation Precautions**
  If the deck is placed near an amplifier, TV or tuner, noise (induced hum) or beat interference may result, especially during FM or AM reception. If this occurs, place the deck further away from other components or reorient its position.



❶ Power Switch (POWER)
Press once to turn the power to deck on, and once more to turn the power off.
The deck remains in a stand-by (non-operative) mode for approximately 2 seconds after it is switched on.

❷ Eject Button (EJECT)
Press this button to open the cassette compartment cover. When the tape is running, press the STOP button first to stop tape transport, then press the Eject button.

❸ Counter Reset Button (COUNTER RESET)
Press this button to reset the tape counter to zero.

❹ Deck A/B Selector (DECK A/B)
Press this button to switch the display between deck A and deck B.

❺ Counter Memory Button (MEMO)
When this button is pressed during forward tape travel, fast rewinding will stop automatically at the tape counter position "0000".
When this button is pressed during reverse tape travel, fast forwarding will stop automatically at the tape counter position "0000". See page 13.

❻ Tape Speed A Control (TAPE SPEED-A)
Use this knob to vary the tape speed. The speed can be varied within a range of approximately ±12% according to the position of the tape speed control knob.

❼ Dolby NR Button (DOLBY NR)
Press the DOLBY NR button and select the Dolby NR type that suits the recording.


Recording without Dolby NR
Recording with Dolby NR type B
(The "B" indicator will light up.)
Recording with Dolby NR type C
(The "C" indicator will light up.)

❽ Dubbing Speed Buttons (DUBBING SPEED)
Pressing the NORMAL button starts regular speed dubbing from deck A to deck B. Press the HIGH button to perform dubbing at double speed. See page 12.

❾ Tape Speed B Control (TAPE SPEED-B)
Use this knob to vary the tape speed. The speed can be varied within a range of approximately ±12% according to the position of the tape speed control knob.

❿ Input Level Control (INPUT LEVEL)
This knob adjusts the recording input level. It affects the level in both channels. See page 10.

⓫ Cassette Compartment Cover
If the cover is not closed completely, the tape transport buttons will remain inoperative.

⓬ Headphone Jack (PHONES)
For private music enjoyment without disturbing others, or for monitoring a recording, a headphone set may be connected to this jack. Use a headphone with an impedance rating of 8 to 1200 ohms. Signals are output according to the position of the Deck A/B selector.
During dubbing, sound is produced from deck A only, regardless of the position of the deck A/B selector.

⓭ Reverse Mode Switch (REV. MODE)
Select the type of tape transport. The reverse mode can be set to
(one side), (continuous playback), RELAY (relay playback).

⓮ Twin Recording Button (TWIN REC)
Pressing this button will set both deck A and B to the recording pause mode. See page 11.

The DN-770R uses independent Dolby NR systems for decks A and B. Set the Dolby NR type for both decks A and B, using the deck A/B selector O to switch between the decks.

⑮ Tape Transport Buttons

PLAY	Play Button	Press to playback tape.
■	Stop Button	Press to stop the tape in any mode.
<<	Fast Rewind Button	Press for fast rewind.
>>	Fast Forward Button	Press for fast forwarding.
REC/REC MUTE	Rec/Rec Mute Button	Press the REC/REC MUTE (•) button and PLAY button simultaneously to start recording. If only the REC/REC MUTE (•) button is pressed, the deck enters the Recording Pause mode. Pressing this button in the Recording Pause mode will start Auto Rec Mute, and a 5-second silent space is recorded onto the tape. See page 11.
REC PAUSE	Rec Pause Button	Press this button to enter the recording pause mode from the recording or recording mute mode. This button can only be used during recording. See page 11.
◀▶	Direction Button	Changes the tape transport direction from forward "▶" to reverse "◀", and vice versa.

⑯ Display

Indicators with an encircled number light up when the corresponding button is pressed.



CASSETTE TAPES

- **Handling Precautions**
- C-120 Cassettes
  C-120 cassette tapes are not recommended as they use a very thin tape base which may become tangled around the capstan or pinch roller.
- Tape Slack Before putting a tape into the deck, take up any slack with a pencil or your finger tip. This precaution prevents the tape from becoming entangled around the capstan or pinch roller.



- **Storage Precautions**
- Do not store cassette tapes in a place where they will be subject to:
  - Extremely high temperature or excessive moisture
  - Excessive dust
  - Direct sunlight
  - Magnetic fields (near TV sets or speakers)
- To eliminate tape slack, store your cassettes in cassette cases with hub stops

- **Accidental Erasure Prevention**
- All cassettes have erasure prevention tabs for each side. To protect valuable recordings from accidental or inadvertent erasure, remove the tab for the appropriate side with a screwdriver or another tool.
- To record on a tape whose erasure prevention tabs have been removed, cover the tab holes with adhesive tape.

AUTOMATIC TAPE SELECTION

This Stereo Cassette Deck contains an automatic tape selector which automatically selects the optimum bias and equalization for the tape in use. This is accomplished by detection of the tape type detections holes in the cassette housing.

- If a tape without tape type detection holes is used, the deck will be set for normal tapes.



PLAYBACK

- The operations described below apply to deck A and deck B alike.
- Switch on your amplifier or receiver.
- Set the Tape Monitor switch on your amplifier or receiver to the TAPE position.
- The numbers in the illustration below depict the order in which operation steps are carried out.



① Press the POWER switch to the ON position.

② Press the EJECT button to open the cassette compartment cover.

③ Load the cassette tape and close the cassette compartment cover.

④ When listening to a tape that has been recorded with Dolby noise reduction, set the DOLBY NR button to match the system used at the time of recording.
Pressing the DOLBY NR button selects Dolby noise reduction type B (and the "B" indicator lights up).
One more press of the DOLBY NR button selects Dolby noise reduction type C (and the "C" indicator lights up).
Pressing the DOLBY NR button once again switches Dolby noise reduction off.

Dolby NR off → Dolby NR type B → Dolby NR C →

⑤ Press the Direction (◀▶) button to select the direction of tape transport.

Transport Direction	Indicator
Forward	▷
Reverse	◁

⑥ Select the type of tape transport with the REVERSE MODE switch.

Mode	Switch Setting
To listen to one side only	⇄
To listen to repeat playback of both sides	↻
To listen to continuous playback of both sides and both decks.	RELAY

⑦ Press the PLAY button to begin playback. The PLAY (4 or D) indicator will light during playback.

⑧ Press the stop button to stop the playback.

- In the continuous playback mode (REVERSE MODE), playback of both tape sides will be repeated 5 times and then stop automatically.
- If different types of Dolby noise reduction are used for record and playback, playback response will be adversely effected.
- When power is turned off during tape transport, it may not be possible to remove the cassette by pressing the EJECT button. In this case, turn on power again before you press the EJECT button.

RELAY PLAY (continuous playback of the tapes in deck A and deck B)

- Load a cassette tape into deck A and B, and set the Dolby NR button correctly on deck A and B.



① REVERSE MODE set to "RELAY".

② Press the PLAY button of the deck you first wish to listen to.
The PLAY indicator of the deck playing back the tape will light up. ~3

③ To stop relay play, press the stop button of the deck currently playing the tape.

- Relay play will play decks A and B in succession for 5 cycles, upon which playback stops. When playback starts from deck B, when switching to deck A, the first deck A playback cycle will be counted as the second cycle. The completion of 5 cycles will always be at the opposite side of the tape in deck B.

NOTE: If both decks A and B are set to the play or record modes while in the relay mode, the relay mode is cancelled and the RELAY indicator turns off. To set the relay mode again, first set both decks A and B to the stop mode.
The RELAY indicator turns back on.

• TWIN OUTPUT

With the DN-770R, it is possible to play tapes simultaneously on decks A and B and output their signals at the same time.
When both decks A and B are played, the signals for deck A are output from the deck A line out jacks, and the signals from deck B are output from the deck A/B line out jacks.

- The deck A line out jacks are exclusively for the deck A signals.
- The deck A/B line out jacks are for both the deck A and deck B signals.
- Use the deck A/B line output jacks when connecting one of the sets of line outputs to a receiver or amplifier.

• MUSIC SEARCH SYSTEM

The music search system detects blank sections (lasting for at least 4 seconds) between selections in order to locate the beginning of selections in the forward or reverse direction.

1. To advance from the current selection to the beginning of the next selection (CUE):
   Press the PLAY button simultaneously with the Fast Forward button when the tape is traveling in the forward direction. Press the PLAY button simultaneously with the Rewind button when the tape is traveling in the reverse direction.
   The deck will skip the rest of the current selection and automatically resume play from the beginning of the next selection.
2. To repeat playback from the beginning of the current selection:
   Press the PLAY button simultaneously with the Rewind button when the tape is traveling in the forward direction. Press the PLAY button simultaneously with the Fast Forward button when the tape is traveling in the reverse direction.
   The deck will rewind the tape to the beginning of the current selection and automatically resume play from that point.
   This is very convenient for repeating playback of the current selection.

Notes on Music Search Operation:

The search functions operates by detecting comparatively long, blank sections approximately 4 to 5 seconds long, in between recorded selections. Therefore, the system may not operate normally in the following cases:

- Recordings with discontinuous speech or conversation.
- Recordings with long periods of pianissimo (softly played music).
- Recordings with long silences.
- Blank sections with a high level of noise.
- Blank sections shorter than 4 seconds.
- If noise-emitting appliances, such as electric razors, drills, refrigerators, etc., are operated nearby.
- REV close the beginning of the program or CUE close to the ending.

RECORDING

The operations described below apply to deck A and deck B alike. Switch on your amplifier or receiver and the source component. Set the Tape Monitor switch on your amplifier or receiver to the SOURCE position.



① Press the POWER switch to the ON position.
② Load the cassette tape.
(Check that the erasure prevention tabs of the cassette housing have not been broken off.)
③ Press the DOLBY NR button and select the Dolby NR type that suits the recording.

Recording without Dolby NR ←
↓
Recording with Dolby NR type B
(The " B " indicator will light up.)
↓
Recording with Dolby NR type C
(The " C " indicator will light up.)

④ Press the Direction (◄►) button to select the direction of tape transport.
⑤ Select the type of tape transport with the REVERSE MODE switch.

Mode	Switch Setting
To record on only one side	⇄
To continuously record on both sides	⬭ or RELAY

⑥ Press the REC/REC MUTE (●) button to set the recording pause mode.
The ● **II** indicator will light up.
⑦ Adjust the recording level with the INPUT LEVEL control while watching the Peak Level Meter.
⑧ Press the PLAY button to start the recording.
The PLAY (◄ or►) and the ● indicator will light during recording.
⑨ To stop recording, press the stop button.
⑩ To pause the recording, press the REC PAUSE (**II**) button. Press the PLAY button to resume recording.

Caution:

- Be careful not to erase important recordings by mistake. Inadvertent start of recording will happen in the following cases:
  1. If the PLAY button is pressed while the 1 indicator lights, recording starts.
  2. If the PLAY and REC/REC MUTE (●) button are pressed at the same time, recording starts.

The best way to avoid accidental erasure is to break off the two erasure prevention tabs on the cassette housing.

- **PROPER RECORDING LEVEL**

A too high recording level can saturate the tape and cause distortion. On the other hand, if the recording level is set too low, soft passages will be marked by residual noise. A proper recording level is the single most important factor for making well balanced recordings.

Guideline for maximum recording level

TYPE I (Normal)	0 dB level on peaks
TYPE II (Cr02)	+1 dB level on peaks
TYPE IV (Metal)	+3 dB level on peaks

Note: The optimum recording level differs depending on the program source and the type of tape used.

- **REC/REC MUTE AND REC PAUSE Button**

1. To record a 5-second blank section during recording:
   Press the REC/REC MUTE (●) button. A 5-second blank will be recorded and the deck will enter the recording standby mode.
2. To record a 5-second blank section during the recording standby mode: Press the REC/REC MUTE (●) button from the recording standby mode. A 5 second blank will be recorded and the deck will enter the recording standby mode again.
3. To cancel recording of blank space:
   Press the REC PAUSE (**II**) button. Blank space recording will be cancelled and the deck enters the recording standby mode.
4. To extend the blank section with another 5 seconds or more:
   Simply press the REC/REC MUTE (●) button and the blank section will be increased with another 5 seconds.

- **AUTO-STANDBY**
  This function is extremely convenient when conducting relay recording, relay playback, twin recording or tape copying.
- When the fast rewind (**<<**) and record pause (**II**) buttons are pressed simultaneously while in the stop mode and the tape is set to play in the forward direction (►), the tape is rewound to the beginning, then played to the end of the leader tape and stopped automatically at the beginning of the magnetic tape.
- When the fast forward (**>>**) and record pause (**II**) buttons are pressed simultaneously while in the stop mode and the tape is set to play in the reverse direction (◄), the tape is fast-forwarded to the end, then played in the reverse direction to the end of the leader tape and stopped automatically at the beginning of the magnetic tape.
- The PLAY indicator flashes during the auto-standby mode.

Caution:
If recording is started after using the auto standby function with a recorded tape, the sound of the previous recording may not be completely erased. In such cases, rewind the tape before starting to record.

- **TWIN RECORDING (simultaneous recording on deck A and deck B)**
  This is a convenient feature for recording the same program source onto two tapes at the same time.
- Load cassette tapes into both deck A and B. Set the Dolby NR button both deck A and B and the REVERSE MODE switch.



① Press the TWIN REC button. The **A+B** indicator will light up and both decks will enter the recording pause mode.
② Adjust the INPUT LEVEL control for the best recording input levels while watching the Peak Level Meter.
③ Press the PLAY button of deck B to start twin recording.
④ To stop twin recording, press the **STOP** button of each deck.

- By pressing the deck B REC PAUSE (**II**) button or the REC/REC MUTE (●) button, the recording pause or recording mute mode on both decks can be set automatically. The deck A (**II**) and (●) buttons cannot be used.
- The relay mode cannot be set with the REVERSE MODE switch when in the twin recording mode.

- **RELAY RECORDING (continues recording from deck A to deck B)**
  To record a long program, start recording on deck A, and when both sides of the tape in deck A have been recorded, the relay recording feature continues to record on the tape in deck B.
- Load cassette tapes into decks A and B, and set the Dolby NR button both deck A/B.



① REVERSE MODE set to "RELAY".
The RELAY indicator will light.

Recording Order	
Deck A	Deck B
Side facing you → Opposite side	→ Side facing you → Opposite side

② Press the REC/REC MUTE (●) button of deck A to set the recording pause mode.

③ Adjust the INPUT LEVEL control for the best recording input level while watching the Peak Level Meter.
④ Press the **PLAY** button of deck A to start relay recording.
⑤ To stop relay recording, press the **STOP** button of the deck that is recording.

NOTE: If both decks A and B are set to the play or record modes while in the relay mode, the relay mode is cancelled and the RELAY indicator turns off. To set the relay mode again, first set both decks A and B to the stop mode.
The RELAY indicator turns back on.

DUBBING (from deck A to deck B)

- Switch on the amplifier or receiver.
- Set the Tape Monitor switch on your amplifier or receiver to the TAPE position.



① Press the POWER switch to the **ON** position.
② load the cassette tape to be played in deck A and the one to be recorded in deck B.
③ Select the type of tape transport with the REVERSE MODE switch.

Reverse mode	Operation
⇄	Dubbing is performed only for one side. The decks stop when either deck A or B reaches the end of the tape.
⇆	The tape direction is reversed on each deck when they reach the end of the tape. (This is convenient for dubbing to a tape with a different length.)
RELAY	During dubbing of the side facing you, the deck that first reaches the end of the tape will stand by until the other deck reaches the end of the tape, then both decks will reverse the tape direction together. (Depending on the manufacturer, the length of tapes having the same recording time may differ somewhat. Setting this mode permits the arrangement of the beginning portion of the opposite side of the tape.)

④ To begin normal speed dubbing, press the DUBBING SPEED NORMAL button. The DUB indicator will light at this time.
To high speed dubbing, press the DUBBING SPEED HIGH button. The HIGH indicator will light at this time.
⑤ To stop dubbing, press the stop of deck A or deck B.

- When deck A is in the playback mode and deck B is in the stop condition, setting deck B to the recording pause mode will engage the normal speed dubbing pause mode. Dubbing is then started by pressing the PLAY button.
- When dubbing, the recording level and the Dolby NR coding will be the same as those of the playback tape, regardless of the positions of the INPUT LEVEL control and the DOLBY NR button.
- When listening to the playback sound during normal speed dubbing, set the DOLBY NR button to match the Dolby NR system with which the playback tape was recorded. This will assure correct sound reproduction, but does not affect the recording.
- The playback sound cannot be heard during high speed dubbing.
  Operation using the REC/REC MUTE (•) and REC PAUSE (**II**) buttons of deck B is permitted during normal speed dubbing.
- Buttons other than the stop button cannot be used during high speed dubbing.

DECK A / B SELECT AND MEMORY STOP



1) Operation of the Deck A/B Selector

(1) Press the RESET button to reset the counter to "0000".

(2) By using the PLAY, FF, or REW functions, the reading of the counter will change to indicate index position.

- During recording and playback operations, the counter is useful for noting the location of existing programs or positions where recording is to be started.
- The reading of this counter does not correspond with that of any other deck.

(3) Deck A and Deck B have the memory of their own counter. Operate COUNTER A/B to change Deck A or B to display its counter.

(4) The level meter and Dolby setting display also switch with the Deck A/B selector.

2) MEMORY STOP Operation

(1) During recording or playback, the Memory Stop feature can be used to locate a particular point on the tape. Press the COUNTER MEMO button at the desired point.

(2) The MEMO indicator lights.

(3) When the Rewind (<<) is pressed during forward tape travel (►), or the Fast Forward (>>) button is pressed during reverse tape travel (◄), the tape is rapidly rewound (or advanced) until the counter indication of "0000" is reached.

- The Memory Stop feature will rewind or forward the tape to within -5 counts in the forward (►) direction (from "0000" to "-0005") and to within +5 counts in the reverse (◄) direction (from "0000" to "0005"). After this, several seconds are required for corrective operations.
- The Memory Stop function operates independently in both directions for deck A and deck B. The MEMO indicator will switch over with the use of the DECK A/B button.

Caution:

If the memory stop operation is performed after repeated fast forwarding or rewinding, the tape may not stop at the proper position.

(3) Display Back-up

(1) The COUNTER VALUE, DECK A/B, MEMO DIRECTION and DOLBY NR functions are protected for approximately one month by a memory back-up.
Once the back-up period is up, the DOLBY NR and MEMO settings are set to off, the DECK A/B setting is reset to "A" the DIRECTION setting is set to (►), and the counter is reset to "0000".

DOLBY B AND C NOISE REDUCTION SYSTEM

- The Dolby noise reduction system substantially reduces the tape background noise (hiss) inherent in the cassette medium. Dolby B NR is most widely in use. However Dolby C NR is a much more recent development and represents significant improvements over Dolby B NR.
- Tape background noise consists primarily of high frequency information, which is particularly annoying during soft passages. The Dolby NR system increases the level of low volume mid- and high-frequency signals during recording and reduces the level of these signals by an identical amount during playback. As a result, the playback signal is identical to the original source, but the level of background noise generated by the tape is greatly reduced.
- The operating principle of Dolby C NR is similar to that of Dolby B NR except for the encoding /decoding response curves. The noise reduction effect obtained with Dolby C NR is up to 20 dB, compared to 10 dB with Dolby B NR. In addition, Dolby C NR uses an anti-saturation network and spectral skewing circuitry for a significant improvement in the dynamic range of the mid- to high-frequencies.

DOLBY HX-PRO HEADROOM EXTENSION SYSTEM

This deck is equipped with the Dolby HX-PRO headroom extension system. Since the system functions automatically during recording, no switching operation or adjustment is required. The system is effective with any type of Normal, Cr02 and Metal tape.

The Dolby HX-PRO headroom extension system functions during recording to raise the saturation level in the treble range. Therefore, most of the treble range components distorted or lost during recording on conventional cassette decks are more faithfully recorded on the new DENON cassette deck.

Features of the Dolby HX-PRO Headroom Extension System

(1) Performance of Normal and Cr02 tapes can be improved to very close of that offered by Metal tape.
(2) The dynamics in the treble range are improved significantly.
(3) Since no decoding is necessary during playback, the improved sound can be enjoyed on any type of tape deck, including portable players and car audio systems.
(4) The system functions whether the Dolby B/C NR system is engaged or not.

MAINTENANCE

- **Head Cleaning**
  After long usage, tape coating or dust may adhere to the heads, causing deterioration of sound. Therefore, the parts depicted in the illustration should be cleaned regularly. Use a cotton swab moistened with a tape head cleaning solution (such as alcohol).

Note:

1. Some cleaning cassettes on the market have strong abrasive effects and may scratch the heads. Always use cotton swabs instead of cleaning cassettes.
2. Since the use of metal tape is apt to collect more dust on the heads, the heads should be cleaned more often to enjoy the best possible sound.



- **Cleaning the Pinch Rollers and Capstans**
  If the pinch rollers or capstans accumulate dust, tape transport may become unstable, as a result from slippage, during recording or playback. The tape can also be damaged if it gets entangled in the capstan.
  Clean these parts with a cotton swab or a soft cloth moistened with a tape head cleaning solution (such as alcohol).
- **Demagnetizing the Heads**
  The heads will become magnetized after long usage or if strongly magnetized objects are brought near them. The result is a generation of noise, loss of the high frequency range, and in extreme cases erasure of treble components on pre-recorded tapes in combination with added noise.
  Thus, the heads should be demagnetized at regular intervals. (Head demagnetizers are separately available from your dealer.)
- **How to Demagnetize the Tape Heads**
  1. Turn **off** the power.
  2. Turn on the demagnetizer while it is at least 30 cm away from the heads. Bring the demagnetizer near the heads and slowly move it in small circles four or five times in front of each head, making sure you do not touch them.
  3. Slowly move the demagnetizer away and turn it off when it is at least 30 cm away from the heads.

TROUBLESHOOTING

Check the following before you draw the conclusion that your Stereo Cassette Deck is malfunctioning. 1. Are all the connections correct? 2. Are all system components being operated correctly in accordance with the operating instructions? 3. Are the speakers and amplifier/ receiver functioning correctly? If the tape deck still does not function properly, check the symptom against the list below. If the symptom does not correspond to the check list, please contact your DENON dealer.

Problem	Cause	Remedy
Tape does not run	• Power cord is disconnected. • Tape is loose. • Cassette is not loaded properly. • Defective cassette.	• Check power cord. • Tighten tape with a pencil, etc. • Load cassette properly. • Replace cassette.
Tape is not recorded when REC/REC MUTE (•) button is pressed.	• No cassette is loaded. • Erase prevention tabs are broken off.	• Load cassette. • Cover holes with adhesive tape.
Sound is warbled and distorted.	• Heads, capstan or pinch roller are dirty. • Tape is wound too tight. • Recording input level is too high. • Tape is worn out and has "drop-outs".	• Clean them. • Fast forward or rewind to loosen tape winding. • Adjust recording input level. • Replace tape.
Excessive noise	• Tape is worn. • Heads, capstan or pinch roller are dirty. • Heads are magnetized. • Recording input level is too low.	• Replace them. • Clean them. • Demagnetize heads. • Adjust recording input level.
High frequency range (treble) is emphasized.	• Dolby NR switch is set improperly.	• Set Dolby NR Switch properly.
High frequency range (treble) is lost.	• Heads are dirty. • Tape is worn.	• Clean them. • Replace tape.
The cassette tape cannot be removed.	• If the POWER switch is turned off either during recording or playback and the unit is stopped, there may be cases when the cassette cannot be removed, even if the EJECT button is pressed.	• Turn the POWER switch ON again, and then press the STOP button. • Now, press the EJECT button to remove the cassette tape.

SPECIFICATIONS

Type	Vertical tape loading; 4-track 2-channel stereo double cassette deck
Heads	Recording/ playback head (Amorphous) x 2 Erase head (Double-gap ferrite) x 2
Motors	Capstan (DC servo motor) x 2 Real (DC motor) x 2
Tape Speed	4.8 cm/ sec.
Variable (PLAY)	Approx. ±12%
Fast Forward, Rewind Time	Approx. 110 sec. with a C-60 cassette
Recording Bias	Approx 105 kHz
Overall S/ N Ratio (at 3% THD level)	Dolby C NR on: more than 74 dB (CCIR/ARM)
Overall Frequency Response	20 --- 18,000 Hz ±3 dB (at-20 dB, Metal tape)
Channel Separation	More than 40 dB (at 1 kHz)
Wow & Flutter	0.06% WRMS, ±0.14% w. peak

Input	
LINE	80 mV (-20 dBm) input level at maximum
Input impedance: 50 kohm unbalanced	
Output	
LINE	775 mV (0 dB) output level at maximum (with 47 kohm load, recorded level of 200 pwb/mm)
PHONES	1.2 mW output level at maximum (optimum load impedance 8 ohm ~ 1.2 kohm)
Power Supply	Voltage is shown on rating label
Power Consumption	Show on rating label
Dimensions	4831W1 x 134 (H) x 2751D) mm (17-3/32" x 4-57/64" x 10-53/64")
Weight	5.4 kg (9 Ibs 11 oz)

* Above specifications and design are subject to change without prior notice.

Dolby noise reduction and HX Pro headroom extension manufactured under license from Dolby Laboratories Licensing Corporation. HX Pro originated by Bang & Olufsen. .
"DOLBY", the double-D symbol and "HX PRO" are trademarks of Dolby Laboratories Licensing Corporation.

WARNING:
INSTRUCTIONS ON THIS SHEET ARE FOR QUALIFIED SOUND INSTALLERS AND SERVICE PERSONNELS ONLY.

Wired Remote Control Box Circuit Diagram

1. Circuit Diagram



L - CH : Vcc (5 VOLT)
R - CH : SIGNAL

SW001 ~ 008: Momentary Contact
SW101, 102: Toggle Switch

SW 008 DECK A/B

DECK SELECTOR button
Press this button to select either Deck A or Deck B to be controlled.

Second and Subsequent Units

- Make a control box using the supplied remote control box connection wire.
- Do not connect the left channel of the plug (Vcc) with 8001 (200 ohm) in the second and subsequent units.
- Use resistors having a tolerance of within ±5% (1 /4W).
  Use of resistors having a poorer tolerance will cause incorrect operation.
- Never short circuit the left-channel line (Vcc). Doing so will damage the main unit.

2. **Operation with Parallel Connections**
   A number of DN-770R units can be simultaneously operated in parallel with 1 button.
   Operation with parallel connections can be used with a maximum of 5 units.
   Connection of 6 or more units will lead to incorrect operation.

3. **Cable Length**
   The longer the length of the cable, the more susceptible the system will be to the effects of external noise.
   Keep cable lengths to 2 m or less.
   Do not locate equipment that produces electrical noise in the vicinity of the cable.
   Doing so might lead to incorrect operation due to the noise.

4. Do not disconnect or connect the remote control plug during operation of the unit.
   The pins of the plug might cause a short circuit of the pins inside the jack which can stop the operation.

5. Pressing more than one button of the wired remote control box at the same time (for combined operations) is not possible. A music search operation will not result from pressing the PLAY and FF, or PLAY and REW buttons at the same time.

6. Pressing a button of the wired remote control box and a button of the main unit, **DN-770R**, (for combined operations) is not possible.

7. When multiple sets are connected to a single remote box, the other sets may operate erroneously when this set's power is turned on or off or when the cord is connected or disconnected from the remote control jack.
   Turn off the remote control box' toggle switches (SW101, 102,…) when turning this set's power on or off or when connecting or disconnecting the cord from the remote control jack while other sets are connected to the remote control box.